



PS316-T11UE-S300

- thermoplastic enclosure with foldable latching cover
- Quick connection technology as connection terminals rotated by 45°
- Simple and quick to adjust the control elements by 45°.
- cable entry 1 x M20 x 1,5
- Design to EN 50041

Data

Ordering data

EAN (European Article Number)

Approval - Standards

Certificates

EAC

cULus CCC

4030661502465

General data

Standards	IEC 60947-5-1
Housing construction form	Norm construction design
Actuator type to DIN EN 50047	В
Enclosure material	Plastic, glass-fibre-reinforced
Material of the contacts, electrical	Silver
Gross weight	112.7 g

General data - Features		
Safety functions	Yes	
Number of auxiliary contacts	1	
Number of safety contacts	1	
Safety appraisal		
Standards	EN ISO 13849-1	
Mission Time	20 Year(s)	
Safety appraisal - Safety outputs		
B10d Normally-closed contact (NC)	20,000,000 Operations	
Mechanical data		
Actuating element	Plunger S300	
Mechanical life, minimum	10,000,000 Operations	
Positive break force, minimum	50 N	
Actuating speed, minimum	60 mm/min	
Actuating speed, maximum	0.5 m/s	
Mechanical data - Connection technique		
Terminal Connector	Screw connection	
Cable section, minimum	0.34 mm²	
Cable section, maximum	1.5 mm²	

Length of sensor	37 mm
Width of sensor	41 mm

Ambient conditions

Degree of protection	IP66 IP67
Ambient temperature, minimum	-30 °C
Ambient temperature, maximum	+80 °C

Ambient conditions - Insulation value

Rated insulation voltage U _i	300 V
Rated impulse withstand voltage U _{imp}	4 kV

Electrical data

Thermal test current	10 A
Required rated short-circuit current to EN 60947-5-1	400 A
Utilisation category AC-15	240 VAC
Utilisation category AC-15	3 A
Utilisation category DC-13	24 VDC
Utilisation category DC-13	3 A
Switching element	1 NO contact, 1 NC contacts
Switching principle	Creep circuit element
Switching frequency	5,000 /h

Schmersal, Inc., 15 Skyline Drive, Hawthorne, NY 10532

The details and data referred to have been carefully checked. Images may diverge from original. Further technical data can be found in the manual. Technical amendments and errors possible. Generated on: 11/9/2021, 11:37 AM