

Options and Accessories

Safety Switches

	Description	Catalog Number
DH030NK 	Neutral Kits	
	30A DG	DG030NB
	60–100A DG	DG100NB
	200A DG, DH (NEMA 1, 3R enclosures)	DG200NK
	30–60A DH	DH030NK
	100A DH	DH100NK
	200A DH (NEMA 4X, 12 enclosures)	DH200NK
	400A DG, DH	DS400NK
	600A DG, DH	DS600NK
	400A fusible DT, 800–1200A DH	DS800NK
	30–100A DT	DT100NK
	200A DT	DT200NK
	400A non-fusible DT	DT400NK
	600A non-fusible DT	DT600NK
	600A fusible DT, 800A DT	DT800NK
	1200A DT	DT1200NK
DS200GK 	Ground Lug Kits Factory-installed ground lug is supplied in all safety switches	
	30–100A DG	DG030GB
	30–100A DH, DT ①	DS100GK
	200A DG, DH, DT	DS200GK
	400–600A DG, 400–1200A DH, 400–1200A DT	DS468GK
DT100BK 	Switching Neutral Bonding Kits ②	
	30–100A DT, 3P, 4P non-fusible	DT100BK
	200A DT, 3P, 4P non-fusible	DT200BK
	400A DT, 3P, 4P non-fusible	DT400BK
	600A DT, 3P, 4P non-fusible	DT600BK
	800–1200A DT, 3P, 4P non-fusible	DT800BK
DS16CP 	Control Pole Kit (For 2P, 3P Switches)	
	400–600A DG, 30–1200A DH, 30–1200A DT	DS16CP
	Multiple key options are included with the control pole kit. Standard keys provide late-make, early-break functionality. Flanged key provides same make, same break functionality.	
DS200EK1 	Auxiliary Contact Kits Auxiliary contact kits are not field installable on shunt trip safety switches	
	All switches (except 30–100A DG) 1NO/1NC	DS200EK1 ③
	All switches (except 30–100A DG) 2NO/2NC	DS200EK2 ③
	NEMA 7/9 switches (30–100A) 1NO/1NC	178C265G05
	NEMA 7/9 switches (30–100A) 2NO/2NC	178C265G06
DS36CL 	Copper Lug Kits	
	30A DH, DT ④	DS16CL
	60A DH, DT ④	DS26CL
	100A DH, DT ④	DS36CL
	200A DH ④	DS46CL
	400A DH (NEMA 4, 4X, 12 enclosures) ⑤	DS56CL
	600–800A DH (NEMA 4, 4X, 12 enclosures) ⑤	DS66CL

Safety Switches, continued

	Description	Catalog Number
DS56CK 	Crimp Lug Pad Kit (NEMA 4, 4X, 12 Enclosures Only)	
	400–600A DH ④	DS56CK
	800A DH ⑤	DS76CK
DS60FP 	400–800A neutral DH ②	DS800CNK
	Fuse Puller Kits	
	30A DH ④	DS30FP
	60A DH ④	DS60FP
DS22JK 	100A DH ④	DS100FP
	200A DH ④	DS200FP
	"J" Fuse Adapter Kits ⑥⑦	
	60A 240V DH ④	DS22JK
DS12FK 	60A DH, DT and receptacle switches ④	DS26JK
	400A 600V DT ⑧	DT400JK
	600A 240–600V DH, 600A DG ⑤	DS600JK
	"R" Fuse Adapter Kits ④	
DS426TK 	30A DG	DG030RB
	100A DG	DG100RB
	30A 240V DH, DT	DS12FK
	30A 600V DH, DT, 60A 240V DH, DT, 60A DG	DS16FK
	60A 600V DH, DT	DS26FK
	100A 240–600V DH, DT	DS36FK
	200A 240–600V DH, DT, 200A DG	DS46FK
	400A 240–600V DH, 240V DT, 400A DG	DS56FK
	600A 240–600V DH, DT, 600A DG	DS66FK
	"T" Fuse Adapter Kits	
	200A 240V DH ④	DS426TK
	200A 600V DH ④	DS466TK
	400A 240V DG, DH, DT ⑤	DS526TK
	400A 600V DH ⑤	DS566TK
	600A 240V DG, DH ⑤	DS626TK
	600A 600V DH ⑤	DS666TK
	600A 240V ⑤	DT626TK
	600A 600V ⑤	DT666TK
	800A 240V DH ⑤	DS726TK
	800A 600V DH, DT ⑤	DS766TK
	Miscellaneous Kits	
	Hookstick handle	DH800HSH
	Lubricating grease for safety switch blades and contacts (each kit contains three 30 cc tubes of lubricating grease)	DSLUBEKIT

Notes

- ① Ground bar kit is not listed on device publications.
- ② Order one kit per switch.
- ③ For duty ratings, see table on following page.
- ④ Order one kit for three poles.
- ⑤ Order one kit for each pole.
- ⑥ 30A Class J available as factory option only.
- ⑦ If Class J fuse kit is not listed, then switch will accept Class J fusing by repositioning either fuse base or fuse clips. No drilling required.
- ⑧ Order one kit for six poles.

Accessories are not applicable to NEMA 7/9 switches unless indicated otherwise.