

Ceiling Box Cover





Mounting screws are invisible on the ceiling

Covers unused 3-1/2" and 4" round and octagonal boxes prior to the installation of a fan or fixture. Non-rusting, paintable plastic.

IMPROVED FEATURES


- Deeper cover works with pan boxes without the need to cut the post
- Use #8 screws provided or back out existing screws to accept notched bracket
- Bracket has two separate cover mounting options. Threaded post pushes in, for flat ceilings, or screws on for textured/uneven ceilings. (see photo below)


BENEFITS

- Attractive cover. Screws don't show on the ceiling
- Plastic eliminates the scratches you get with painted metal covers
- Covers poorly cut drywall


CATALOG	UPC/DCI/NAED	BOX	UNIT	STD	DIM	DIM	DIM
NUMBER	MFG #018997	SIZE	PKG	PKG	A	B	C
CP3540	54090	3-1/2 & 4"	1/Bag	50 Bags	.437	5.390	.812

Two #8-32 x 3/4" flat head screws and bracket are included. **PATENTED.**









INSTALLATION INSTRUCTIONS



Back the screws out enough to slip the bracket on.



Use the opening in the bracket most suitable for your ceiling condition...
'A' for flat ceilings, push post into opening to seat cover;

'B' for uneven or textured ceilings, screw threaded post into opening until tight.



