


# RESOURCE RFB® SERIES FLOOR BOXES

Floor Boxes with Rectangular Activations


## RFB4-SS Multiservice Shallow Steel Floor Box Accessories Ordering Information

### RFB-B-SS Internal Blank Bracket



Used to close off unused gangs.


### RFB-4TK0-SS Internal Bracket



Four (4) RJ keystone opening knockouts. Use as blank plate or for up to four RJ openings.


**NOTE:** Opening dimension is 9/16" x 3/4" (14.3mm x 19.1mm)

### RFB-RB-SS Internal Duplex Receptacle Bracket



Accepts standard 15A and 20A duplex receptacles.


### RFB4-SS-AAP Internal A/V Bracket



Accepts two (2) Extron® Electronics AAP Series devices, sold separately.


**NOTE:** For RFB4-SS Series Floor Boxes only.

### RFB-GFI-SS Internal GFI Bracket



Accepts standard GFCI and decorator-style receptacles, communication or A/V devices.


### RFB4-SS-MAAP Internal A/V Bracket



Accepts two (2) Legrand AVIP or Extron Electronics MAAP Series devices, sold separately.


**NOTE:** For RFB4-SS Series Floor Boxes only.

### RFB-2AB-SS Internal Bracket




Two Pass & Seymour® Activate™ adapters included. Wiremold CM Series Open System inserts sold separately.

### RFBKIT Barrier Kit



Barrier kit used to separate power and communication wires in partition feed covers. Supplied with base and three extensions to adjust to cover height. Kit should be used on RFB2, RFB2-OG, RFB2-SS, RFB4 and RFB4-SS Floor Boxes. Kits are sold separately.

### RFB-2-SSRT Communication Bracket



Ortronics® AB2TJ TracJack and ABS2 Series II adapters included.

**NOTE:** Additional configurations available. Please consult your local Sales Representative for more information.